


FRONT WHEEL, BRACKET AND HARDWARE  
LB5 LB8



45 5, 6, 7 HP  
18 8, 10 HP

## LEAF BLOWER PARTS LIST

ITEM NO.	PART NO.	QTY.	DESCRIPTION
1	705-0088-G	1	LOWER FRAME WELDMENT WITH GUSSET
2	030-0240	2	4.10/3.50 – 6 PNEUMATIC WHEEL – <b>ALL EZ MODELS</b>
2	703-0108	2	4.10/3.50 – 4 PNEUMATIC WHEEL – <b>LB800, LB1100</b>
3	090-0536	3	SHAFT COLLAR
4	705-0132	1	METAL HANDLE BAR BRACE
5	090-0072	4	5/16-18 X 2" HHCS
6	705-0034	1	UPPER HANDLEBAR ASSEMBLY
7	705-0002	1	HANDLEBAR GRIP
8		1	<b>ENGINE – SEE PART # AT END OF THIS LIST</b>
9	090-0090	4	5/16-18 X 1 1/2" HHCS – <b>800 SERIES MODELS</b>
10	703-0424	1	1/4 X 1/4 X 2 KEY
11	705-0095	1	ENGINE HOUSING WELDMENT
12	090-0408	4	5/16-24 X 3/4" HHCS
13	090-0394	4	5/16 SPLIT LOCKWASHER
14	705-0180	1	IMPELLER
15	090-0021	1	3/8-24 X 1 1/4" HHCS
16	705-0097	1	HOUSING SPACER – <b>1100 &amp; 1350 SERIES MODELS</b>
17	705-0093	1	FRONT HOUSING WELDMENT
18	090-0090	11	5/16-18 X 1 1/2" HHCS – <b>1100 &amp; 1350 SERIES MODELS</b>
19	703-0021-A	1	IMPELLER HOUSING COVER
20	705-0100	1	CHUTE WELDMENT - <b>LB800</b>
20	705-0104	1	CHUTE WELDMENT – <b>1100 &amp; 1350 SERIES MODELS</b>
21	705-0108	1	DIVERTER WELDMENT ASSEMBLY – <b>LB800</b>
21	705-0110	1	DIVERTER WELDMENT ASSEMBLT – <b>1100 &amp; 1350 MODELS</b>
22	090-0225	1	3/8" INTERNAL TOOTH LOCKWASHER
23	701-0185	1	DIVERTER HANDLE GRIP
24	705-0113	1	DIVERTER CLIP
25	090-0052	1	1/4-20 X 1/2" HHCS
26	090-0378	2	1/4 SPLIT LOCKWASHER
27	090-0232	5	1/4 USS FLATWASHER
28	703-0425	1	DIVERTER EXTENSION SPRING
29	090-0480	1	1/4-20 X 5" CARRIAGE BOLT – <b>LB800</b>
29	090-0481	1	1/4-20 X 6" CARRIAGE BOLT – <b>1100 &amp; 1350 SERIES MODELS</b>
30	705-0098	1	DEFLECTOR – <b>LB800</b>
30	705-0099	1	DEFLECTOR – <b>1100 &amp; 1350 SERIES MODELS</b>
31	090-0223	2	1/4" INTERNAL TOOTH LOCKWASHER
32	705-0049	1	ADJUSTMENT KNOB – 1/4-20 THREAD
33	090-0503	4	5/16-18 X 5/8" SELF TAPPING HHCS
34	705-0014	1	FRONT WHEEL BRACKET – <b>LB800, LB1100</b>
35	705-0056-2	1	1/2" SHOULDER BOLT
36	500-0010	2	WHEEL SPACER
37	703-0025	1	FRONT WHEEL – <b>LB800, LB1100</b>
38	090-0461	1	3/8-16 NYLOCK NUT
39	090-0418	20	5/16-18 WHIZ NUT
40	090-0540	1	2" FLATWASHER
41	090-0460	12	5/16-18 NYLOCK NUT
42	705-0150	1	LIFT HANDLE – <b>MC &amp; M MODELS</b>
43	090-0228	1	3/8 SPLIT LOCKWASHER
44	090-0233	6	5/16 USS FLATWASHER
45	090-0067	11	5/16-18 X 5/8" HHCS
46	705-0159	1	WHEEL SUPPORT – TOP BRACKET
47	705-0160	1	WHEEL SUPPORT – BOTTOM BRACKET
48	705-0161	1	WHEEL BRACKET WELDMENT

49	030-0264	1	PIVOT WHEEL BEARING
50	090-0088	2	5/16-18 X 1" HHCS
51	030-0263	1	2.80/2.50-4 WHEEL
52	090-0613	1	1/2 X 4" CLEVIS PIN
53	100-0015	1	3/32 HAIR SPRING
54	705-0166	1	WHEEL LOCK PIN
55	709-3409	1	SPRING
56	090-0454	1	ROLL PIN
57	704-0199	1	BATTERY BOX – BACK
58	704-0202	1	BATTERY BOX SPACER
59	030-0244	1	BATTERY
60	704-0198	1	BATTERY BOX – FRONT
61	090-0615	2	WASHER
62	705-0165	2	ENGINE SPACERS – <b>1350 SERIES MODELS</b>
63	090-0077	4	5/16-18 x 4" HHCS – <b>1350 SERIES MODELS</b>
64	090-0066	2	5/16-18 X 3/4" HHCS

## ENGINES

MODEL	ENGINE #
LB800	030-0504
LB800EZ	030-0504
LB1100	030-0507
LB1350ICEZ	030-0508
LB1350ICEZMC	030-0508
LB1100EZM	030-0507