



PS322TE

**PARTS LIST FOR SPRAYER  
MODEL PS322TE**

ITEM NO.	PART NO.	DESCRIPTION	QUANTITY
1	108-0066	Main Frame Weldment	1
2	108-0095	Rear Axle	1
3	908-0029	Tow Hitch Weldment	1
4	108-0025	Hose Rack Weldment	1
5	100-0221	22 Gal. Tank (Includes Lid & Screws)	1
7	108-0054	Tank Band	2
10	703-0108	Wheel (4.10/3.50-4 Pneumatic)	4
11	108-0318	Electric Pump	1
12	100-0031	Bulk Head Fitting	2
13	100-0088	Nylon Ell 1/2" x 3/8"	1
14	108-0170	Suction Hose - 3/8	1
15	108-0322	Spray Hose - 3/8	1
16	908-0032	Front Axle Weldment	1
17	500-0012-P	Front Wheel Spacer	2
18	090-0457	Push Nut Cap	4
19	100-0139	Plastic Hose Clamp	4
20	100-0141	Plastic Plug 1/2"	1
21	108-0313	Swivel Ell Adapter	1
22	108-0321	Straight Swivel Adapter	1
23	509-0009	Spring	2
24	090-0088	5/16"-18 x 1" HHCS	6
25	090-0079	Tap bolt 5/16"-18 x 2-1/2"	2
26	090-0078	Tap bolt 5/16"-18 x 2"	2
29	090-0233	Flat Washer 5/16"	6
30	090-0442	5/8"-11 Half Hex Nut	1
31	100-0143	Male Hose Insert 3/8"	1
32	090-0460	5/16"-18 Nylock Nut	12
34	908-0060	Axle Bracket	2
35A	500-0071	Axle Spacer, 7/8" Lg.	2
35B	500-0072	Axle Spacer, 1-1/2" Lg.	2
36	090-0210	Hex Nut 5/8"-11	1
37	908-0030	Pull Handle (Optional)	1
38	500-0041	Handle Grip (Optional)	2
39	090-0112	3/8"-16 x 1-1/2" HHCS (Optional)	1
40	090-0461	3/8" Nylock Nut (Optional)	1
41	090-0234	Flat Washer 3/8" (Optional)	2
-	100-0159	Spray Gun Kit Complete	-
42	108-0347	Spray Gun with extension and tip	1
47	090-0400	#10-32 x 1-1/4" Rd. Hd. Machine Screw	4
48	090-0401	Flat Washer #10-32	4
49	706-1539	Kep Nut #10-32	4
---	108-0315	Wire Assembly - Switch to Battery	1
---	108-0314	Wire Assembly - Switch to Pump	1
---	108-0328	On/Off - Rocker Switch	1
---	108-0414	Battery Hold Down	1